

PVX Multimount® | Tube

The PVX Multimount® can be used in **two ways** when installing a pipe.

You can both enter and insert the tube. The installation time for the PVX Multimount® is **10 seconds**.

PVX MULTIMOUNT ART NR:23011945	TUBE LOCKERS ART NR:14092003	PIPE
		

ENTRY STEP 1	ENTRY STEP 2	ENTRY STEP 3
		
FRONT PIPE ENTRANCES 2 X Ø 16-32MM	PLACE THE TUBE IN THE TRANSIT	PRESS THE LOCKER

INSERT STEP 1	INSERT STEP 2	INSERT STEP 3
		
REMOVE THE LID BY PRESSING THE SIDE	BOTTOM WITH INLAY TUBE 2 X Ø 16-32MM	PLACE THE LID / PRESS THE LOCKER

